



Installation Guidelines & Edge Clip Installation

STEP 1




Align edge clip with frame

STEP 2




Push onto frame

STEP 3




Assure all prongs are engaged and clip is fully seated onto frame

STEP 4



Secure cable tie around cable(s) to desired tension

STEP 5



Ensure cable tie is tightened directly adjacent to edge clip housing and the bundle is not pulled laterally after the cable tie is secured.

HellermannTyton North American Corporate Headquarters

7930 N. Faulkner Rd, PO Box 245017, Milwaukee, WI 53224-9517

Phone: (414) 355-1130, (800) 537-1512 • Fax: (414) 355-7341, (800) 848-9866

email: corp@htamericas.com • www.hellermann.tyton.com

TS16949, ISO 9001, and ISO14001 certified

© HellermannTyton Corporation

HellermannTyton

www.hellermann.tyton.com